


SONOFF

TX US


Quick Guide V2.2



Wi-Fi Smart Wall Switch

EN > DE > ES > FR > IT > RU > PT

1




To avoid electric shocks, please consult the dealer or a qualified professional for help when installing and repairing.

1

Power off
Ausschalten
Apagado
Eteindre
Spegnimento
Включить
Desligar

2




Neutral input
Nullleiter-Eingang
Entrada de neutro
Entrée neutre
Ingresso neutro
Вход нуля
Entrada neutro


2

Wiring instruction
Verkabelungsanleitung
Instrucciones de cableado
Instrucciones de câblage
Istruzioni per il cablaggio
Инструкция по подключению проводки освещения
Instrução para instalação de lâmpadas

Light fixture wiring instruction
Anleitung zur Verkabelung von Leuchten
Instrucciones de cableado de aparato deluminarias
Instrucciones de câblage du plafonnier
Istruzioni per il cablaggio della lampada
Инструкция по подключению проводки освещения
Instrução para instalação de lâmpadas



Appliance wiring instruction
Anleitung zur Verkabelung von Geräten
Instrucciones de cableado de aparatos
Instrucciones de câblage de l'appareil
Istruzioni per il cablaggio dell'apparecchio
Инструкция по подключению оборудования
Instrução para instalação de eletrodoméstico




3

!

Make sure the neutral wire and live wire connection is correct.
Vergewissern Sie sich, dass der Anschluss von Neutralleiter und stromführender Phase korrekt ist.

3

Download App
APP herunterladen
Descargar la aplicación
Télécharger l'application
Scarica la App
Скачать приложение
Baixe o App



4

LIKE IT!

Glad to know you are satisfied with SONOFF products.
It would mean a lot to us if you can take a minute to share your buying experience.



Share it on Amazon



Share it on your social media



Share it with your friends and family



HAVE A PROBLEM?

We are so sorry for the inconvenience caused by the product.
Please contact us for help via the email address below.




support@tead.cc

We will get back to you as soon as possible.

SONOFF

YOUR SMART HOME CHOICE

4



After powering on, the device will enter the quick pairing mode (Touch) during the first use.
The Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.

5


Power on
Einschalten
Encender
Allumer
Accensione
Включить
Ligar

!

The device will exit the quick pairing mode (Touch) if not paired within 3mins.
If you want to enter this mode, please long press any configuration button for about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.

6

5



Tap "+" and select "Quick Pairing", then operate following the prompt on the APP.
Tippen Sie auf "+" und wählen Sie "Schnellkopplung" und arbeiten Sie dann gemäß der Aufforderung auf der App.

7

Add the device
Gerät hinzufügen
Añadir el dispositivo
Ajouter l'appareil
Aggiungere il dispositivo
Добавить устройство
Adicione o aparelho

User Manual



https://sonoff.tech/usermanuals

Scan the QR code or visit the website to learn about the detailed user manual and help.
Scannen Sie den QR-Code oder besuchen Sie die Website um auf die detaillierte Bedienungsanleitung zuzugreifen und Hilfe.

Escanee el código QR o visite el sitio web para consultar la guía del usuario detallada y ayuda.
Scannez le code QR ou visitez le site web pour consulter le guide détaillé et aide.

Scansione il codice QR o visita il sito web per consultare la guida utente dettagliata e aiuto.
Сканируйте этот QR-код или перейдите на наш веб-сайт для просмотра подробного руководства пользователя и помощи.

Scannez le code QR pour lire les instructions de contrôle vocal de l'Amazon Echo et Google Home.
Scannen Sie den QR-Code, um die Anweisungen für die Sprachsteuerung für Amazon Echo und Google Home zu lesen.

Escanee el código QR para leer las instrucciones del control por voz de Amazon Echo y Google Home.
Scannez le code QR pour lire les instructions de contrôle vocal de l'Amazon Echo et Google Home.

Scannez le code QR para ler as instruções para controle de voz Amazon Echo e Google Home.

8

Scan the QR code to read the voice control instruction for Amazon Echo and Google Home.
Scannen Sie den QR-Code, um die Anweisungen für die Sprachsteuerung für Amazon Echo und Google Home zu lesen.

Escanee el código QR para leer las instrucciones del control por voz de Amazon Echo y Google Home.
Scannez le code QR pour lire les instructions de contrôle vocal de l'Amazon Echo et Google Home.

9

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

- Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

Shenzhen Sonoff Technologies Co., Ltd.
1001, BLDG8, Lianhua Industrial Park, shenzhen, GD, China
ZIP code: 518000
Website: sonoff.tech

MADE IN CHINA



Table with 2 columns: Attribute (品牌, 物料, 材料, 规格, 日期) and Value (松诺/SONOFF, TX-US 快速指南 V2.2, 105g铜版纸 四色印刷 手风琴6折页, 展开: 420x115mm 折后: 70x115mm, 2021.08.04)